


## NEW FEATURES

### IN COMPARISON WITH TESTOMAT ECO®

- integrated SD Card:
  - Data and alarm/error logging onto SD card
  - Firmware update via SD card
  - Import and export of settings
- Transfer of measuring data and status via RS232 interface
- Optional connection of a fieldbus converter or a converter for telecommunication networks.
- Optional: WLAN Access for wireless write access on SD card



- **Testomat® EVO TH CAL** with calibration function to compensate for interfering influences by external ions

## COMPANIES OF THE HEYL NETWORK

### Germany

**Gebrüder Heyl Vertriebsgesellschaft  
für innovative Wasseraufbereitung mbH**

[www.heylnemeris.de](http://www.heylnemeris.de)

Phone: +49 (0) 51 21 76 09 0

Fax: +49 (0) 51 21 76 09 44

Email: [vertrieb@heylnemeris.de](mailto:vertrieb@heylnemeris.de)

### France

**Heyl Analysis Technologies**

[www.hey-at.com](http://www.hey-at.com)

Phone: +33 (0) 1 69 46 17 17

Fax: +33 (0) 1 69 46 17 40

Email: [contact@hey-at.com](mailto:contact@hey-at.com)

### The Netherlands

**Pro Water B.V.**

[www.prowater.nl](http://www.prowater.nl)

Phone: +31 (0) 74 2 91 51 50

Fax: +31 (0) 74 2 91 53 50

Email: [info@prowater.nl](mailto:info@prowater.nl)

### USA

**Heyl Brothers North America L.P.**

[www.heybros.de](http://www.heybros.de)

Phone: +1 (0) 312 377 61 23

Fax: +1 (0) 312 644 07 38

Email: [USA@hey.de](mailto:USA@hey.de)

### Switzerland

**BWT AQUA AG**

[www.bwt-aqua.ch](http://www.bwt-aqua.ch)

Phone: +41 (0) 61 755 88 99

Fax: +41 (0) 61 755 88 90

Email: [info@bwt-aqua.ch](mailto:info@bwt-aqua.ch)

### Production and Development

**Gebrüder Heyl Analysetechnik GmbH &  
Co. KG**

[www.heyanalysis.de](http://www.heyanalysis.de)

Phone: +49 (0) 51 21 2 89 33 0

Fax: +49 (0) 51 21 2 89 33 67

Email: [info@heyanalysis.de](mailto:info@heyanalysis.de)

Flyer Testomat EVO GB 200730

## TESTOMAT® EVO TH

ONLINE ANALYSIS UNIT FOR RESIDUAL  
TOTAL HARDNESS (WATER HARDNESS)



*also available as  
Testomat® EVO TH CAL  
with calibration function*



**GEBRÜDER HEYL**  
Analysetechnik GmbH & Co. KG  
Wasser ist unser Element

## OVERVIEW

### TESTOMAT® EVO TH

The analysis unit Testomat® EVO TH is an on-line analysis unit, which determines residual total hardness (water hardness) in water via titration and following photoelectrical evaluation.

The indicator is pumped into the water filled measuring chamber by a piston dosing pump until the colour changes. The measuring value will be calculated with the amount of metering strokes.

Measuring of total hardness with 4 types of indicator in a range of 0,05 - 25 °dH or 0.89 to 448 ppm CaCO<sub>3</sub>

The **Testomat® EVO TH** is qualified for monitoring and controlling the water quality in:


- Water treatment plants
- Industrial boilers
- Monitoring of process water
- Drinking water systems
- and much more

## PARAMETER/INDICATOR TYPE

UNIT	TH 2005	TH 2025	TH 2100	TH 2250
<b>°dH</b> (resolution)	0,05 - 0,50 (0,01)	0,25 - 2,50 (0,05)	1,0 - 10,0 (0,2)	2,5 - 25,0 (0,5)
<b>°f</b> (resolution)	0,09 - 0,89 (0,02)	0,45 - 4,48 (0,1)	1,8 - 17,9 (0,4)	4,5 - 44,8 (1,0)
<b>ppm CaCO<sub>3</sub></b> (resolution)	0,89 - 8,93 (0,2)	4,5 - 44,8 (0,9)	18 - 179 (3,8)	45 - 448 (10)
<b>mmol/l</b> (resolution)	0,01 - 0,09 (0,01)	0,04 - 0,45 (0,01)	0,18 - 1,79 (0,04)	0,45 - 4,48 (0,1)

## ELECTRICAL CONNECTIONS

### TESTOMAT® EVO TH



Our customers of Geonwater B.V./Netherlands use the Testomat® EVO TH CAL to measure water hardness. They particularly appreciate the calibration function of the device.

## TECHNICAL DATA

### TESTOMAT® EVO TH

**Power supply:** 230 VAC or 100 - 240 VAC ± 10 %, 50-60 Hz

**Power consumption:** max. 230 V (100-240 V)/4 A, without external load 230 V (100-240 V)/1 A

**Protection class:** I

**Degree of protection:** IP65

**Conformity:** EN 61326-1, EN 61010-1 

**Ambient temperature:** 10 – 40 °C

**Measuring range:** 0,05 - 25 °dH / 0.89 to 448 ppm CaCO<sub>3</sub>

**User power supply:** Switched power supply with 4 A fuse-protected

**Durability relay:** DC: 8 A at 30 V or 0,28 A at 250 V; AC: 8 A at 415 V

**Current loop:** 0/4 – 20 mA, max. load 500 ohm corresponding to 10 V voltage, voltage isolated

**Dimensions:** W x H x D = 380 x 480 x 280 mm

**Weight:** approx. 9,0 kg

The device is power-failure protected.

### Water connection

**Working pressure:** 11 to 8 bar / 1x10<sup>5</sup> to 8x10<sup>5</sup> Pa or 0,3 to 1 bar / 0,3x10<sup>5</sup> to 1x10<sup>5</sup> Pa (after removing of the valve body out of the regulator/filter housing)

**Water temperature:** 10 – 40°C

**Water intake:** Opaque hose with 6/4x1 mm external diameter

**Water drain:** Hose with internal diameter 12 mm